


Camera connection (for Auto transmission)

The camera cord is provided only when you buy the backup camera from us.



1. Red wire-connect to **“Reversing output +12V” (red wire).**
2. Yellow RCA jack, connect to **“CAMERA VIDEO”** jack (yellow color) of navigation unit.
- 3 & 4, not need to use. But must package them separately well to avoid short circuit.